

TDMA Easy Programming

THIS IS THE PREFERRED PROGRAMMING METHOD

Before you start,

- Write down your client's cellular phone number here () - ,
- your Carrier Analog System ID* (a one to five digit number) here ,
- and your Carrier Digital System ID* here .

*Contact your Cellular Service Provider to confirm your Carrier System ID number.

	TO	ENTER	PHONE DISPLAYS
1	Enter Programming Mode	PRESS (#), Carrier System ID, (#), (*), (SEND)	Nam 1 Prog * = Yes # = No
2		PRESS (*)	Security Code _ _ _ _ _
3	Enter Security Code	PRESS (0), (0), (0), (0), (0), (0) (This is the code that is in the phone when it is shipped out of the factory.)	Phone displays its ESN (Electronic Serial Number)
4		PRESS (SEND)	Phone # _ _ _ _ _
5	Enter Phone Number	ENTER Entire Phone Number () -	
6		PRESS (SEND)	Nam Program Begins

Don't worry! If you make a mistake, press (CLR) to erase the last digit or press and hold (CLR) to erase the entire entry. Re-enter the correct number, then press (SEND) and you're finished!

