

This taps to the RED/white stripes cable found under the ECU cover.

This brown cable is your fade in/out effect. Tap it to the driver's side footwell light. You will have to go through the drivers side firewall which has a small access (rubber hole). This can be accessed by taking away the under cover of the steering wheel near the pedals.

Relay. Mount this somewhere in the engine bay (close to the power battery connector)

This goes to the battery power connector in the engine bay.

Ground cable. There are some possibilities closeby

These connect to your ICE v2's second pair of leads. The actual connectors do not match, so you will have to solder them together or splice the cable and use some electric tape to connect them. RED from wiring harness to RED on the ICE and BROWN from wiring harness to BLACK on the ICE.

