



# Parts and Accessories. Installation Instructions.

## Retrofit white tail lights BMW 5 Series Saloon (E60)

**Retrofit kit No.** 63 21 301 815

### Installation time

The installation time is 0.5 hours, but this may vary depending on the condition of the car and the equipment in it.

### Important information

These installation instructions are primarily designed for use within the BMW dealership organisation and by authorised BMW service companies.

In any event the target group for these installation instructions is specialist personnel trained on BMW cars with the appropriate specialist knowledge.

All work must be completed using the latest BMW repair manuals, circuit diagrams, servicing manuals and work instructions in a rational order using the prescribed tools (special tools) and observing current health and safety regulations.

### Pictograms



Denotes instructions that draw your attention to dangers.



Denotes instructions that draw your attention to special features.

◀ denotes the end of the instruction or other text.

See the EBA CD or Aftersales Portal for explanations of the pictograms.

Do not archive the hard copy of these installation instructions since daily updates are made by Aftersales Portal.

Subject to technical modifications.

### Installation information

Replace the existing tail lights with the white tail lights as described in TIS No. 63 21 180.



The DIADEM lamps may only be fitted in the positions intended for them. ▶

### Special tools required

None