
65 20 090

Removing and installing/replacing antenna amplifier (diversity)



Necessary preliminary tasks:

- Remove head restraint at rear left.
- Remove panel for roof pillar on rear left.



Unlock plug connections (1) and disconnect. Release screws (2). Remove antenna amplifier (3) in direction of arrow.