
51 44... Removing and installing front roofliner trim



Necessary preliminary tasks:

Remove ceiling light (front)



Unclip front roofliner trim (1) in direction of arrow.

Disconnect associated plug connections and remove front roofliner trim (1).