**Special tools required:**


- 64 1 020

**Important!**

Follow instructions for handling light bulbs (interior lights).

Replacement:

If necessary, remove bulb.


**In footwell:**

Lever out footwell light (1) with special tool 64 1 020 as illustrated.

Disconnect associated plug connection and remove footwell light (1).

Replacement:

Note type of bulb.



On underside of door:

Lever out footwell light (1) with special tool 64 1 020 as illustrated.

Disconnect associated plug connection and remove footwell light (1).

Replacement:

Note type of bulb.