

Release screws (1).

*Note:*


Feed in screwdriver (2) of sufficient length as illustrated ahead of trim for instrument panel (4).

Unclip upper retaining points (3) by pressing screwdriver (2) towards front.

Unclip lower retaining points (5).

Unlock associated plug connections and disconnect.

Remove center trim for instrument panel (4).



Replacement:

- Remove operator unit for heater/air conditioner
- Remove center console switch center