

About...

Read error memory

E R R O R M E M O R Y

-----  
Date: 05.01.2014 12:03:02  
ECU: LM\_60  
JobStatus: OKAY  
Variant: LM\_60  
-----

RESULT: 1 error in error memory !  
-----

E519 alive signal of ALC system is missing

Error counter: 36

Mileage 132904 km

Implausible signal or value  
Test conditions fulfilled  
Error present now and already stored  
Error would not cause a warning lamp to light up

Error code: E5 19 68 24 40 E5  
=====