

[BMW E60 525d Sedan](#) / [Repair Manuals and Technical Data](#) / [17 Cooling](#) / [17 11 Engine oil cooler and mounting parts](#) /

17 11 035 Replace the fan cowl with the electric fan (M47T2, M57T2, N47, N46T)




When the engine is stopped after the end of the journey, operation of the electric fan may be necessary. In rare cases, operation of the electric fan can last up to 11 min. This is for component protection. In this context, renewing the electric fan will not remedy the problem!




Necessary preliminary tasks:

- Remove the [radiator cover](#)



Unlock connector (1) and pull off.



Release mounting screw.

Remove fan cowl (1) in direction of arrow.

For informational purposes only. The information on this website is provided AS-IS with no warranties, express or implied, and is not guaranteed to be error-free, up-to-date or complete. NewTIS and BMW assume no liability for any loss or damage arising from the use or reliance on the information and content on this website. The content on this website is subject to change without notice.