

ERROR MEMORY

Date: 18.11.2023 17:45:48
 Model: E60
 Scope: all control module
 JobStatus: OKAY
 Quantity: 29

ADR	Gen. name	JobStatus	Number of errors
	Error code	Kind of error	
00	ZGM	OKAY	1 Error stored
	93B2	61	
01	SIM/SGM	OKAY	No Error stored
02	SZL	OKAY	1 Error stored
	94F7	28	
12	DME/DDE	OKAY	6 Error stored
	2F4C	02	
	2F4A	02	
	2F7B	44	
	2DEC	02	
	2E98	04	
	2E84	04	
17	EKP	OKAY	No Error stored
18	EGS	OKAY	1 Error stored
	507D	28	
20	RDC	OKAY	4 Error stored
	6054	E0	
	6055	E0	
	6056	E0	
	6057	E0	
27	PGS	OKAY	No Error stored
29	DSC	OKAY	1 Error stored
	5F12	E0	
36	TEL/MULF	OKAY	1 Error stored
	D68D	20	
37	AMP	OKAY	No Error stored
40	CAS	OKAY	5 Error stored
	A0C1	22	
	A0C2	22	
	A0B4	60	
	A0B5	64	
	A11D	28	
41	DWA	OKAY	No Error stored
44	SHD/MDS	OKAY	No Error stored
45	RLS	OKAY	No Error stored
50	SINE	OKAY	1 Error stored
	9D44	11	

55	ISPB	OKAY	No Error stored
5E	GWS	OKAY	2 Error stored
	E094	21	
	E095	21	
60	KOMBI	OKAY	3 Error stored
	9315	28	
	A554	20	
	A559	20	
62	MOSTGW	OKAY	2 Error stored
	E18D	20	
	E18F	20	
63	MMI/CCC	OKAY	1 Error stored
	ABCA	20	
64	PDC	OKAY	1 Error stored
	9E32	A4	
65	BZM/SZM	OKAY	2 Error stored
	9FF1	24	
	9FF2	24	
67	ZBE	OKAY	No Error stored
6D	FAS	OKAY	No Error stored
70	LM	OKAY	7 Error stored
	9CB7	24	
	A8BD	24	
	9CAA	62	
	A8C5	24	
	A8BC	24	
	A8B5	24	
	9CB9	62	
72	KBM	OKAY	3 Error stored
	A418	20	
	A419	20	
	A428	24	
73	CID	OKAY	No Error stored
78	KLIMA	OKAY	1 Error stored
	9C55	61	

=====