


Note:

Extend steering wheel completely and lower.



Necessary preliminary tasks:

Version with electric steering wheel adjustment only:

- **E60:** Remove luggage compartment trim on side panel on right
- **E61:** Open battery cover
- **E63/E64:** Remove luggage compartment floor trim panel with fitted mat
- **All:** Disconnect battery negative lead



Release screws (1).

Pull back instrument cluster (2) slightly.

Unlock associated plug connection and disconnect.

Feed out/unclip associated wiring harness.

Remove instrument cluster (2).



Replacement:
Carry out programming/coding.