



R31 0140

- | | | | |
|---|-----------------------------|----|--------------------|
| 1 | Spring strut shock absorber | 10 | Upper spring pad |
| 2 | Lower spring pad | 11 | Thrust bearing |
| 3 | Coil spring | 12 | Dust sleeve |
| 4 | Auxiliary spring | 13 | Thrust washer/shim |
| 5 | Wheel arch | 14 | Rubber gaiter |
| 6 | Upper spring plate | | |
| 7 | Centering pin | | |
| 8 | Grease cap | | |
| 9 | Nut | | |