
## 63 10 004 Adjusting headlights



Note:

Comply with test preconditions for headlight adjustment.



Adjust headlights at adjusting screws (1) and (2). A definite allocation of adjusting screws is not possible.

- 1. Adjustment screw primarily for vertical adjustment
- 2. Adjustment screw primarily for lateral adjustment