

**Warning!**

If work is carried out in area of airbag systems, e.g. on:

- Door trim panels
- Interior trims
- Instrument panel etc.

the ignition must be turned off in each case.

- The ignition must always be off.
- The ignition key must be removed from the ignition lock.

This eliminates the risk of injury.