

## 61 31 115 Replacing rocker switch for side window operation (front)




## Necessary preliminary tasks:

• Remove front door trim panel.



## Unscrew nut (1).

Unlock catches (2) and remove rocker switch for side window operation (3) downwards out of front door trim panel (4).



## Installation:

Retaining hook (1) and plastic pin (2) must not be damaged. Make sure rocker switch for side window operation (3) is installed in correct position.