

SICHERUNGEN IM GEPAECKRAUM / FUSES IN TRUNK

	89	Heated seats / gear indicator lighting, etc.		50,56	Rain headlight sensor		82	Tire pressure control RDV
	53,74,83	Comfort access, Seat adjust.		50	Headlight washer pump		52,81	Air Suspension
	51	Alarm siren / Auto dim rear view mirror		62,65	Trailer module for E60 M5		87,88	Front Cig lighter, glove box charging socket, rear cig lighter
	74,78	DSC, Driver, Pass seat adjustment		69	Park distance control		72	Fuel pump control, Fuel pump relay
	70,71,86	Cruise ctrl, SMG, active steer		51	Anti theft alarm system siren.		77,79	Heads up display / Central info display
	78,80,84,85	DSC / Gear Indicator / Active Cruise / SMG		57	Heating / Air Conditioning		66	Sunroof, Panorama glass, convertible top module.
	89	Electrochromic rear view mirror.		57,61,64	Heating, A/C, Cooler box		59,73,75, 77,80	HiFi Amp, TV tuner, Video Module
	56	Rain / Headlight Sensor		63	Independent auxiliary heater		80	Hi Fi Amp, Telephone
	81	Electronic ride height control.		54	Rear window defogger		71	Electric rear sunshade for E60 M5
	52	Air suspension compressor relay.		58	Rear wiper relay		60	Roll over protection controller
							52,66	Convertible relay, Sunroof
							60	Rollover protection controller
							76	Dynamic drive / Boot lid lift.
							55,61	Boot lid lift / Cooler box.
							62,66,67	Relay for rear window motors, Automatic softclose doors.
							70	Adaptive headlight, Active cruise control, Close range sensor

FUSE-NO.
AMPERE

85	86	87	88	89
7,5	40	20	20	5

FUSE-NO.	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84
AMPERE	5	10	30	20	30	5	10	10	10	5	10	10	7,5	7,5	30	15

FUSE-NO.	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68
AMPERE	30	5	40	30	30	40	5	7,5	20	5	10	7,5	30	20	15	20	20	20	20

SICHERUNGEN IM HANDSCHUHFACH / FUSES IN GLOVE BOX

	1	Dynamic Stability Control		10,11,12,18, 22,24,27,29, 36	Door module, OBD2 socket		4,19	Active steering, EDC
	10,12,17,18, 25,28,29	SMG, Steering, DSC.		10,11,12,22, 24,27,29	Door module, Body gateway		2	Fuel Heater, Secondary air pump relay
	10,12,29,32	Body gateway module		14,21	Seat adjust		18,35	Navigation System
	5,6,19	Light Module		26,31,33	Heat, A/C		18,34	CCC/M-ASK
	11,22,24,27	Basic Body Module		20	OBD, Ind Aux heater.		18,38	CD Changer, Body gateway module.
	18,33,41	Instrument cluster.		11,16,22,24, 27	Wiper system.		18,37	Telephone
	13,19	Gear indicator, EDC, Gearbox Control.		11,22,24,27	Basic body module		7,15	Car access system.
	8,23,31	DME, IVM		3	Blower Output Stage		30	Fuel pump relay
				9	Electric Fan			



FUSE-NO.	1	2	3	4	5	6	7	8	9
AMPERE	50	50	40	20	40	40	30	60	60

\* M5/M6

FUSE-NO.	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46
----------	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

6 978 267.9 ENS55U