**Special tools required:**

- 31 2 220

**Warning!**


Danger of burning and other injuries!

Only perform this work after engine has cooled down.


Removal of the exhaust system must be carried out with the assistance of a second person.

Note:


Weight of exhaust system is approx. 40 kg.





Support exhaust system with special tool 31 2 220 .




Unfasten nut.




Release screw.



If fitted: Pull off vacuum hose (1).
Unscrew nuts (1).



Unfasten screws.
Remove reinforcement plate.
Lower exhaust system carefully.



Installation:

Check exhaust system for leaks.