The ones that are marked with an X have been confirmed to work with that specific year model. Please help out by marking the ones you've successfully coded and fill out any missing information or add additional features

Name	Module	Module Value	2006	2007	2008	2009	2010	2011	Description
Adaptive Headlight Error	NFRM	CHECK_SMC_ERROR							Removes the adaptive headlight error check
All High Beams		PWM_WERT2_FL_BIXENON							Change "wert_02" to "wert_01" to have both the bixenons and the halogen as high beams
Audio System	CIC	Audio System				X	X	X	Selects CIC audio outputs from Stereo (High Level, front full range, rear high pass analog signals, 25W max); HiFi (low level, 5V, front and rear full range, Balanced analog signals); and Top_HiFi (MOST fiber optics, proprietary dig
Auto Dim Mirrors	CAS	SPIEGEL_ELEKTROCHROM			X		X		nicht_aktiv to turn off autodim mirror
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_SL_V							Cold testing bulbs in parking light - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_SL_V							Warm testing bulbs in parking lights - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_AL							Cold testing bulbs in low beam - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_BL_MI							Cold testing bulbs in brake light - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_BLK_HI							Cold testing bulbs in turn signal rear - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_BLK_VO							Cold testing bulbs in turn signal - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_FL							Cold testing bulbs in high beam - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_KZL							Cold testing bulbs in number plate - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_KZL_LI							
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_NSW	X						Cold testing bulbs in foglights - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	KALTUEBERWACHUNG_RL							Cold testing bulbs in reversing light - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACH_low beams_BLK							
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_AL							Warm testing bulbs in low beams - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_AL_L							Warm testing bulbs in low beams - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_BL_MI							Warm testing bulbs in brakes - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_BLK_HI							Warm testing bulbs in rear turn signals - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_BLK_VO							Warm testing bulbs in front turn signals - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_FL							Warm testing bulbs in high beams - change setting to NOT ACTIVE
Bulb Testing Warning	CAS	WARMUEBERWACHUNG_KZL_LI							Warm testing bulbs in number plate light bulb - change setting to NOT ACTIVE
Close Windows/Roof	CAS	KOMFORTSCHLIESSUNG_FB	X	X	X	X	X	X	Closes windows + moon roof with FOB
Close Windows/Roof	CAS	KOMFORTSCHLIESSUNG_PA			X	X	X	X	Closes windows + moon roof through comfort access
Corner Delete Mod	FRM	SIDEMARKER_US	X	X	X				Disables side marker/signal light when headlights are on. Module value might be longer than SIDEMARKER_US. Here are some examples: SIDEMARKER_US_NFRM or it could be SIDEMARKER_US_NF.
Corner Delete Mod	NFRM	PO_RL_FKT_MIT_SL_V			X				Disables side marker/signal light when headlights are on.
Corner Delete Mod	NFRM	PWM_SL_V_BEI_AKTIVEN_AL			X	X			Disables side marker/signal light when headlights are on. Module value might be longer than SIDEMARKER_US. Here are some examples: SIDEMARKER_US_NFRM or it could be SIDEMARKER_US_NF.
Corner Delete Mod	NFRM	PWM_SL_V_BEI_AKTIVEN_FL			X	X			Disables side marker/signal light when headlights are on. Change the value to "wert_04"
Corner Delete Mod	NFRM	SIDEMARKER_US_MIT_FRA_V						X	Disables side marker/signal light when headlights are on. Change setting to NOT ACTIVE
Corner Delete Mod	NFRM	SIDEMARKER_US_NFRM			X	X			Disables side marker/signal light when headlights are on.
Digital MPG	KOMBI	DIGITAL_KVA	X	X	X		X	X	Displays digital instant-read MPG in cluster
Digital Speed	KOMBI	BC_DIGITAL_V	X	X	X	X	X	X	Displays digital speed in cluster (2011: Resets ECU and service counter/dates. Be sure to write down or take a picture of your service counter/dates before coding.)
Digital Speed Value	KOMBI	V_DIGITAL_KORRECTOR		X	X	X			If set to nicht_aktiv, digital speed will give true car speed (not speedometer speed). If set to aktiv, digital speed will be same as speedometer.
Disable iDrive Disclaimer	CAPPL (CCC)	LEGAL_DISCL	X	X	X				Disables iDrive legal disclaimer during iDrive startup. This is for the earlier E90 with CCC module.
Disable iDrive Disclaimer	CIC Unit	LEGAL_DISCLAIMER_TIME				X	X	X	Disables iDrive legal disclaimer during iDrive startup. Change the value: ld_mit_timeout --> kein_ld
Door Dong	KOMBI	CC_ZUENDSCHLUESSEL		X	X		X		Disables dong when driver's door is open and key is in slot. May reset ECU and service counter/dates.
DRL High Beam Delete	NFRM	TAGFAHRLICHT_ECE_1				X			Disables the Daytime Running Lights (High Beam) Canadian models. * At this point I have not yet been able to turn on the AE's as DRL's *
DRL High Beam Delete	FRM	DRL_V_GEDIMMT		X					Disables the Daytime Running Lights (DRL) on Canadian models. This is sub-module FRM, my car did not have an NFRM sub-module.
DRL option in iDrive	CAPPL (CCC)	DAY_RUN_LIGHT_CCC	X		X				Adds a submenu with DRL option (On,Off) in iDrive settings. Change "nicht_aktiv" to "aktiv"
DRL Taillight Delete	NFRM	DRL_TFL_MIT_RL_BL_2			X				Disables taillights when DRL is on. Change "aktiv" to "nicht_aktiv"
DVD Playback	CIC Unit	VIDEO_NUR_MIT_HANDBREMSE				X	X		Enables DVD playback when car is stopped regardless of what gear but not in motion. *Remove DVD from drive before coding
DVD-In Motion	CAPPL (CCC)	VIDEO_DENY_C0B			X				TV / Video while driving activation. Change "deny_slow_key" to "deny_never"
Eject Key Fob with Engine Off	CAS	KOMFORT_EJECT					X	X	When turning the engine off key fob will be ejected from socket. (Think you need comfort access option for this to work)
Engine Start	CAS	ANLASSSPERRE_BLS							Start engine without pressing the brake (Does not work on 2010) - spazticrecords
Fog Lights + Flash	LMA	LH_UND_NSW_NICHT_GLEICHZ			X	X	X		Allows fog lights to stay on when the high beams are flashed. Change to nicht_aktiv
Fog Lights + Flash	NFRM	LH_UND_NSW_NICHT_GLEICHZ			X	X	X	X	Allows fog lights to stay on when the high beams are flashed. Change to nicht_aktiv
Fog Lights + High Beam	LMA	FL_UND_NSW_NICHT_GLEICHZ			X	X	X		Allows fog lights to stay on when the high beams are on. Change to nicht_aktiv
Fog Lights + High Beam	NFRM	FL_UND_NSW_NICHT_GLEICHZ			X	X	X	X	Allows fog lights to stay on when the high beams are on. Change to nicht_aktiv
Fold Mirror	NFRM	ASP_KOMFORT_EINKLAPP					X	X	Folds side mirrors with FOB and CA
Fold Mirror	NFRM	BEIKLAPPEN_B_KOMFORTSCHL							Folds side mirrors with FOB
Fold Mirror	NFRM	SPIEGEL_KOMFORT_EINKLAPP		X	X	X			Folds side mirrors with FOB
Fuel Stop Suggestion in Route Guidance	CIC	NAVI_FUELSTOP_PROPOSAL				X	X	X	Go to "Route Information" on iDrive when you're going somewhere and it will tell you at what point(s) along your journey you'll likely need to fill up. You can then select that notice and it will tell you about the stations in the area at t
iDrive Default Screen Communication	CAPPL (CCC)	VA_FB_COMMUNICATION	X						iDrive screen switches to Communication few seconds after startup (assumed--only tested VA_FB_ENTERTAINMENT).
iDrive Default Screen Entertainment	CAPPL (CCC)	VA_FB_ENTERTAINMENT	X						iDrive screen switches to Entertainment a few seconds after startup.
iDrive Default Screen Navigation	CAPPL (CCC)	VA_FB_NAVIGATION	X						iDrive screen switches to Navigation a few seconds after startup (assumed--only tested VA_FB_ENTERTAINMENT).
iDrive Display Modes	CIC	NAVI_MAPMODE_AUTOMATIC		X			X		Adds a submenu with 3 options under Day Mode (day, night, auto) (***DOES NOT WORK ON E90 2010/11 or E92 2009/01)
Left Parking lamp malfunction error massega	FRM	FEHLERMELDUNG_CC_SL_V_L	X						remove the warning from your BMW idrive when you install HID's or angel eyes
Lock/unlock beep option in iDrive (part 1)	CAPPL (CCC)	ACOUSTIC: aktiv	X			X			Adds a submenu for lock/unlock beep in iDrive Settings (must have alarm installed)
Lock/unlock beep option in iDrive (part 2)	CAPPL (CCC)	C941C_QUITT_AKUST_KLAPPE: fkt_frei	X						Adds a submenu for lock/unlock beep in iDrive Settings (must have alarm installed)
Lock/unlock beep option in iDrive (part 3)	CAPPL (CCC)	K9416_QUITT_AKUST_ENTSCH: fkt_frei	X						Adds a submenu for lock/unlock beep in iDrive Settings (must have alarm installed)
Lock/unlock beep option in iDrive (part 4)	CAPPL (CCC)	C9413_QUITT_AKUST_SCHAERF: fkt_fre	X						Adds a submenu for lock/unlock beep in iDrive Settings (must have alarm installed)
Panic Mode	CAS	SONDERTASTE_PANIKALARM	X			X			Enables panic alarm. Must have alarm installed. Hold trunk botton on FOB for 5 secs to activate. Change from "nicht_aktiv" to "panikalarm"
Rain Close	Which module?	REGENSCLIESSENTILT				X			Automatically closes the moon roof when rain is detected. Wiper rain sensor must be turned on for this function to work.
Right Parking lamp malfunction error message	FRM	FEHLERMELDUNG_CC_SL_V_R	X						remove the warning from your BMW idrive when you install HID's or angel eyes
Seat Belt Chime	ABG	SBR_BEIFAHRER_1		X	X				Disables seat belt chime for passenger side
Seat Belt Chime	ABG	SBR_BEIFAHRER_2_CD			X	X			Disables seat belt chime for passenger side (CIC)
Seat Belt Chime	ABG	SBR_FAHRER_1		X	X				Disables seat belt chime for driver side
TPMS Disable	V.O. in FA string	$2vb							fault comes back after long drives...will update with new fix. Please be sure to follow the format of the column by entering the correct values. If this is simply an edit of the V.O. then please leave those fields blank then type the inst
Unlock Doors	CAS	ER_KEYOUT_AUTOVR	X	X	X	X	X	X	Unlocks all doors when you remove key (2009: Only unlocks driver door if FOB set to unlock driver door only. Set FOB to unlock all doors, and this will unlock all doors, too) (also works with Comfort Access when engine is shut off,

I've added a Q&A tab at the bottom.