

# BMW 335i (N54) Maintenance Schedule

Version 1.1b, Note: All numbers in miles, use this at your own risk.. Information partially derived from the "Old School Maintenance Schedule v04 2009")

	1,200	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000	67,500	75,000	82,500	90,000	97,500	105,000	112,500	120,000	127,500	135,000	142,500	150,000	157,500	165,000	172,500	180,000	187,500	195,000	202,500	210,000
<b>Oil &amp; Filter Change</b> Replace every 7,500 BMW Recommends every 15,000	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
<b>Tires</b> Inspect tread depth, wear pattern, condition, inflation pressure Replace when below minimums	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
<b>Battery</b> Inspect state of charge every 15,000 Replace on failure			I		I		I		I		I		I		I		I		I		I		I		I		I		I
<b>Wheel Alignment</b> Inspect every 15,000 or every year BMW recommends yearly and when replacing tires			I		I		I		I		I		I		I		I		I		I		I		I		I		I
<b>Brake Fluid</b> Replace every 30,000 or every 2 years BMW recommends every 2 years					R				R				R				R				R				R				R
<b>Manual Transmission Clutch Fluid</b> Replace every 30,000 BMW recommendation unknown					R				R				R				R				R				R				R
<b>Interior Air Filter</b> Replace every 15,000 BMW recommends 15,000			R		R		R		R		R		R		R		R		R		R		R		R		R		R
<b>Engine Air Filter</b> Inspect every 15,000, replace every 30,000 BMW recommends 45,000			I		R		I		R		I		R		I		R		I		R		I		R		I		R
<b>Change Engine Coolant</b> Inspect PH/hydrometer every 15,000 or every year Replace every 30,000 or every 2 years BMW states lifetime fluid			I		R		I		R		I		R		I		R		I		R		I		R		I		R
<b>Power Steering Fluid</b> Change every 30,000 BMW states lifetime fluid					R				R				R				R				R				R				R
<b>Manual Transmission Gearbox Oil</b> Change every 60,000 BMW states it is a lifetime fluid	R								R							R										R			

I = Inspect, R = Replace

# BMW 335i (N54) Maintenance Schedule

Version 1.1b, Note: All numbers in miles, use this at your own risk.. Information partially derived from the "Old School Maintenance Schedule v04 2009")

	1,200	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000	67,500	75,000	82,500	90,000	97,500	105,000	112,500	120,000	127,500	135,000	142,500	150,000	157,500	165,000	172,500	180,000	187,500	195,000	202,500	210,000	
<b>Differential Oil</b> Change every 60,000 miles BMW states it is a lifetime fluid	R								R							R									R					
<b>All-Wheel-Drive Transfer Cases</b> Change every 30,000 BMW states it is a lifetime fluid					R				R							R					R					R				R
<b>Spark Plugs</b> Replace every 45,000 BMW recommends 45,000							R						R					R								R				
<b>Automatic Transmission Fluid &amp; Filter</b> Replace every 60,000 BMW recommends 100,000									R							R										R				
<b>Fuel Filter</b> Replace every 150,000 or on failure BMW states lifetime filter																						R								
<b>Engine Drive Belts</b> Inspect every 15,000, replace 120,000 BMW recommendation unknown			I		I		I		I		I		I		I		R		I		I		I		I		I		I	
<b>Oxygen Sensors</b> Replace every 120,000 or on failure BMW recommends 120,000																						R								
<b>Water and Fuel Hoses</b> Inspect every 30,000, replace every 150,000 BMW recommendation unknown					I				I				I				I					R				I				I

I = Inspect, R= Replace

I = Inspect, R = Replace